



IONIC EQUILIBRIUM

AKK SIR (AKHILESH KANTHER)

Q. 100ml, 0.1 M HCl is mixed 0.1 M NaOH

Volume of $[H^+]$ or $[OH^-]$

pH

NaOH added

0 ml

$$[H^+] = 0.1M$$

1

~~B 11-13 R~~

90 ml

$$[H^+] = \frac{1}{190} = \frac{1}{1.9} \times 10^{-2}$$

$$2 - \log \frac{1}{1.9} = 2.3$$

99 ml

$$[H^+] = \frac{0.1}{199} = \frac{0.1}{200}$$

$$3 - \log 1/2 = 3.3$$

101 ml

$$[OH^-] = \frac{1}{2} \times 10^{-3}$$

B

~~5-7 R~~

$$pOH = 3.3, pH = 10.7$$

$$[OH^-] = \frac{0.1}{201} = \frac{0.1}{200} = \frac{1}{2} \times 10^{-3}$$

Q. 100ml, 0.1 M HCl is mixed 0.1 M NaOH

Volume of $[H^+]$ or $[OH^-]$ pH
NaOH added

0 ml $[H^+] = 0.1M$ 1

90 ml $[H^+] = \frac{1}{190} = \frac{1}{1.9} \times 10^{-2}$ $2 - \log \frac{1}{1.9} = 2.3$

99 ml $[H^+] = \frac{0.1}{199} = \frac{0.1}{200}$ $3 - \log 1/2 = 3.3$

101 ml $= \frac{1}{2} \times 10^{-3}$ $pOH = 3.3, pH = 10.7$

$[OH^-] = \frac{0.1}{201} = \frac{0.1}{200}$

IONIC EQUILIBRIUM

In acid base titration, pH changes suddenly near the equivalence point. This sudden change in pH depends on acid-base pair being titrated.

The selection of indicator must satisfy the condition that "pH range of indicator must lie within this sudden jump or fall".

IONIC EQUILIBRIUM

$SA \rightarrow 3$

$SB \rightarrow 11$

$WA \rightarrow 6$

$WB \rightarrow 8$

IONIC EQUILIBRIUM


(1) Titration of Strong acid with strong Base

e.g. HCl + NaOH

IONIC EQUILIBRIUM

(1) Titration of Strong acid with strong Base


e.g. HCl + NaOH



IONIC EQUILIBRIUM

(1) Titration of Strong acid with strong Base

e.g. $\text{HCl} + \text{NaOH}$




IONIC EQUILIBRIUM

(2) Titration of Strong base with strong acid $\rightarrow$
e.g. $\text{NaOH} + \text{HCl}$

IONIC EQUILIBRIUM

(2) Titration of Strong base with strong acid



IONIC EQUILIBRIUM


(3) Titration of weak acid with strong Base

e.g. $\text{CH}_3\text{COOH} + \text{NaOH}$

CH_3COONa

IONIC EQUILIBRIUM


(3) Titration of weak acid with strong Base



IONIC EQUILIBRIUM

(3) Titration of weak acid with strong Base

e.g. $\text{CH}_3\text{COOH} + \text{NaOH}$



IONIC EQUILIBRIUM


(4) Titration of weak base with strong acid

e.g. NH₄OH + HCl

IONIC EQUILIBRIUM


(4) Titration of weak base with strong acid

e.g. $\text{NH}_4\text{OH} + \text{HCl}$



IONIC EQUILIBRIUM


(5) Titration of Strong acid with weak Base



IONIC EQUILIBRIUM


(5) Titration of Strong acid with weak Base

e.g. $\text{HCl} + \text{NH}_4\text{OH}$



IONIC EQUILIBRIUM

(6) Titration of weak acid with weak Base



Jump $\text{pH}_{\text{eq}} \pm 2$

Range: $\text{pK}_{\text{In}} \pm 1$


If $\text{pK}_{\text{In}} = \text{pH}_{\text{eq}}$

Condition for
most suitable
indicator

IONIC EQUILIBRIUM

Double indicator acid base titration :

Example : Na₂CO₃ with HCl



IONIC EQUILIBRIUM

Double indicator acid base titration :

Example : Na_2CO_3 with HCl

$\text{Na}_2\text{CO}_3 + \text{HCl} \rightarrow \text{NaHCO}_3 + \text{NaCl}$ pH changes from (10 – 8)

$\text{NaHCO}_3 + \text{HCl} \rightarrow \text{H}_2\text{CO}_3 + \text{NaCl}$ pH changes from (6 – 3)

IONIC EQUILIBRIUM

Example : Na_2CO_3 with HCl



Let the number of moles of $\text{Na}_2\text{CO}_3 = x$


Find number of moles HCl required to change the colour of solution

(1) If phenolphthalein is used as indicator $n_{\text{HCl}} = x$

(2) If Methyl orange is used as indicator $n_{\text{HCl}} = 2x$

IONIC EQUILIBRIUM

Example : Na_2CO_3 with HCl



Let the number of moles of $\text{Na}_2\text{CO}_3 = x$

Find number of moles HCl required to change the colour of solution

(1) If phenolphthalein is used as indicator $n_{\text{HCl}} = x = n_{\text{Na}_2\text{CO}_3}$

(2) If Methyl orange is used as indicator

$$\underline{\underline{n_{\text{HCl}}}} = 2x = 2 \times n_{\text{Na}_2\text{CO}_3}$$

IONIC EQUILIBRIUM

Q. Find number of moles Na_2CO_3 if 5 moles HCl are required to change the colour of solution

(1) If phenolphthalein is used as indicator (5)

(2) If Methyl orange is used as indicator (2.5) or ~~10~~

IONIC EQUILIBRIUM

Sol. (1) If phenolphthalein is used as indicator

$$n_{\text{Na}_2\text{CO}_3} = n_{\text{HCl}} = 5 \quad \checkmark$$

(2) If Methyl orange is used as indicator

$$2 \times n_{\text{Na}_2\text{CO}_3} = n_{\text{HCl}} = 5 \quad \checkmark$$


IONIC EQUILIBRIUM

Q. A mixture contains both Na_2CO_3 and NaHCO_3 . Find number of moles of each if 2 moles HCl are required to change the colour of solution if phenolphthalein is used as indicator and 7 mole of HCl are required to change the colour of solution if Methyl orange is used as indicator separately.

IONIC EQUILIBRIUM

Sol. (1) If phenolphthalein is used as indicator

$$\chi = \underline{n_{\text{Na}_2\text{CO}_3}} = \underline{n_{\text{HCl}}} = 2$$



(2) If Methyl orange is used as indicator

$$\underline{2 \times n_{\text{Na}_2\text{CO}_3}} + \underline{n_{\text{NaHCO}_3}} = n_{\text{HCl}} = 7$$

$$n_{\text{NaHCO}_3} = 3$$

$$2x + y = 7$$

$$4 + y = 7$$

IONIC EQUILIBRIUM

Q. A mixture contains both Na_2CO_3 and NaHCO_3 . Find number of moles of each if 2 moles HCl are required to change the colour of solution if phenolphthalein is used as indicator. Then Methyl orange is added to this solution and further titrated with HCl . 7 moles of HCl are required to change the colour of solution.

DPP-17

J-Main

IONIC EQUILIBRIUM

Sol. (1) If phenolphthalein is used as indicator

$$n_{\text{Na}_2\text{CO}_3} = n_{\text{HCl}} = 2$$

(2) If Methyl orange is used as indicator

$$n_{\text{Na}_2\text{CO}_3} + n_{\text{NaHCO}_3} = n_{\text{HCl}} = 7$$

$$n_{\text{NaHCO}_3} = 5$$